




# Lenovo IdeaPad N586 Wifi card Replacement

How to replace the wifi card

Written By: Christopher





## TOOLS:


- [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Battery



- To unlock the battery, flip the laptop over so that the bottom is facing upward. Then unlock the left clip by pushing the clip to the left.

## Step 2



- Now push the right clip to the right and hold it while using your other hand to pull the battery out.




## Step 3 — Back Panel





- Remove the two screws highlighted.

## Step 4





- This is the back of the laptop with the cover removed.

## Step 5 — Wifi card



- Remove the white and black wires.


## Step 6



- Next, unscrew the wifi card



## Step 7



- Pull out the wifi card.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 09:52:40 PM.